

PACKING LIST For:

KIT - 57K3492

6/23/04

UNDERBODY PROTECTION (M998A AND M1113 WITH WINCH)
1 KIT

Segregated Pack	GOV'T PART #	AMG PART # if different	NOMENCLATURE	QTY PERKIT	NOTES
					APPLY MIL-STD-130 PLASTIC LABEL TO ITEMS HIGHLIGHTED IN BOLD. (SEE PRINT IF *)
1	B1821BH038C150N	MS90728-64	SCREW, 3/8 - 16 X 1 1/2	2	PLACE INTO BAG. HEAT SEAL OR STAPLE AND APPLY SEGREGATED PACK NO. 1 LABEL.
1	9430677	MS90728-34	SCREW, 5/16 - 18 X 1	12	
2	12460145-1		SCREW, 3/8 - 16 X 2 1/4	1	PLACE INTO BAG. HEAT SEAL OR STAPLE AND APPLY SEGREGATED PACK NO. 2 LABEL.
2	B1821BH038C113N	MS90728-61	SCREW, 3/8 - 16 X 1 1/8	7	
2	9428795	MS90728-71	SCREW, 3/8 - 16 X 3 1/4	5	
3	12460145-2		SCREW, 3/8 - 16 X 2	1	PLACE INTO BAG. HEAT SEAL OR STAPLE AND APPLY SEGREGATED PACK NO. 3 LABEL.
3	2436162		WASHER, 5/16 FLAT	36	
3	9422299		NUT, 7/16 - 14 P. T.	4	
4	MS51943-39		NUT, 1/2 - 13 P. T.	4	PLACE INTO BAG. HEAT SEAL OR STAPLE AND APPLY SEGREGATED PACK NO. 4 LABEL.
4	2436163		WASHER, 3/8 FLAT	38	
4	9430724	MS90728-73	SCREW, 3/8 - 16 X 3 3/4	1	
5	MS51943-35		NUT, 3/8 - 16 P. T.	19	PLACE INTO BAG. HEAT SEAL OR STAPLE AND APPLY SEGREGATED PACK NO. 5 LABEL.
5	453039		SCREW, 5/16 - 18 X 2 3/4	6	
6	12447149		WASHER, SPECIAL	4	PLACE INTO BAG. HEAT SEAL OR STAPLE AND APPLY SEGREGATED PACK NO. 6 LABEL.
6	MS51943-33		NUT, 5/16 - 18 P. T.	18	
6	B1821BH038C100N	MS90728-60	SCREW, 3/8 - 16 X 1	4	
7	12338186-69		SPACER, REAR	9	CUSHION WRAP 6 X 12 SMALL AIR CAP AND APPLY SEGREGATED PACK NO. 7 LABEL.
	12447143	*	SHIELD ASM, INTERMED.	1	
	12447144	*	SHIELD ASM, REAR	1	
	12447145	*	BRACKET, REAR MTG.	3	
	12447146	*	BRACKET ASM, MTG. - LH	1	
	12447147	*	BRACKET ASM, MTG. - RH	1	

PACKING LIST For:

KIT - 57K3492
UNDERBODY PROTECTION (M998A AND M1113 WITH WINCH)
1 KIT

12447148	*	BRACKET, TUBE SUPT.	2	
12447150	*	SHIELD, FUEL TANK	1	
12447151	*	SHIELD, TRANSFER CASE	1	
12447163-2		SKID PLATE	1	
12460415		SHIELD ASM., FRONT	1	
12460291		INSTALLATIONS INSTRUCTIONS	1	8 sheets
12460292		INSTALLATIONS DRAWING	1	4 sheets

PLACE SEGREGATED PACK BAGS 1 THROUGH 6
PLUS SEGREGATED PACK 7 INTO A WP1029 CARTON
AND WATER TAPE.
PLACE CARTON ABOVE AND ALL OTHER ITEMS INTO
A WOOD BOX SHIPPER 61 X 28 X 7-1/4.

LINE BOTTOM OF BOX WITH CREPE KRAFT PAPER
AND CUSHION WRAP OR SEPARATE PARTS AS
REQUIRED WITH "PAD PACK" CUSHIONING.
IF DRAWINGS ARE AVAILABLE PLACE INTO BAG AND
HEAT SEAL OR STAPLE. PLACE ON TOP OF PARTS IN
WOOD BOX.

START BY LOADING 12447143 ON BOTTOM.

PLACE 12460415 OVER 12447143.

PLACE 12447144 OVER 12447143.

PLACE 12447151 NEST TO 12460415.

PLACE 12447146 ON BOTTOM NEXT TO 12447144.

PLACE 12447147 ON BOTTOM NEXT TO 12447144.

PLACE HARDWARE CARTON NEXT TO 12447146 AND
12447147.

PLACE 12447150 ON TOP OF 12447143 AND 12460415.

PLACE 12447163-2 ON TOP.

INCLUDE A COPY OF THIS PACKING SHEET AS A

PACKING LIST.

NAIL AND BAND BOX.

APPLY KIT LABEL OR BAR CODE AND

IDENTIFICATION LABELS AS REQUIRED.

REVISIONS

LTR	DESCRIPTION	DATE (YR-MO-DA)	APPROVED
A	REDRAWN WITH CHANGE (AMG U1770)	00-07-24	CD 137

DRAWING CONTROL	AM General Corporation					
CHANGE DATE	CHANGE NO.	CHG. LET.	CHANGE	DATE	DR.	CK.
RL/1-23-98	144-493		PROD. RELEASE	10-19-98	ZS	
A/7-24-00	144-51008		REV. A ADDED PER PROP. 00-109M ELP-V1770	1-23-02		SE
A/7-25-00	144-51132		SMT. 6, PARA. C & D REVISED EARN 1832, PREP T 6369	1-24-02		SE

NOTES:

1. APPLICABLE STANDARDS/SPECIFICATIONS:
A. DOD-STD-00100D(AR)

INSTALLATION INSTRUCTIONS UNDERBODY PROTECTION ACCESSORY KITS

SECTION I. INTRODUCTION

- 1-1. PURPOSE. THE PURPOSE OF THESE INSTRUCTIONS IS TO PROVIDE A PROCEDURE FOR INSTALLATION OF UNDERBODY PROTECTION ACCESSORY KITS ON 1-1/4 TON TRUCK, M1113 AND M1114 SERIES M998A2 VEHICLES.

M998A2

REV STATUS OF SHEETS	REV	A1	A	A	A	A	A1	A	A									
SHEET		1	2	3	4	5	6	7	8									

PMIC NA		CONTRACT NUMBER DAAE07-92-C-R010		U.S. ARMY TANK-AUTOMOTIVE COMMAND WARREN, MICHIGAN 48397-5000							
APPLICATION											
NEXT ASSY	USED ON	CONTRACTOR AM GENERAL CORP. ENGINEERING & TECHNICAL SERVICES DIV. LIVONIA, MICHIGAN		INSTALLATION INSTRUCTIONS, UNDERBODY PROTECTION ACCESSORY KITS 57K3492, 57K3493, 57K3494, AND 57K3495							
57K3495	M1113	DRAWN BY HB	DATE (YR-MO-DA) 97-05-02	SIZE A				CAGE CODE 19207		12460291	
57K3494	M1114	CHECKER JRC	ENGINEER R PAVOL								
57K3493	SERIES	DRAWING APPROVAL Gray 00-08-22		SCALE NONE				UNIT WT. _____		SHEET 1 OF 8	
57K3492	M998A2	DESIGN APPROVAL P. Blazynski 00-08-22									
MATL ENGR D.F.		Dr 00/04/13									

SECTION II. INSTALLATION KIT

2-1. NEW MATERIAL. INSTALLATION KITS, 57K3492 FOR M998A2 AND M1113 WITH WINCH, 57K3493 FOR M1114, 57K3494 FOR M1113 WITHOUT WINCH, AND 57K3495 FOR M998A2 WITHOUT WINCH, CONTAIN THE FOLLOWING ITEMS. QUANTITIES MAY VARY FROM KIT TO KIT DEPENDING ON VEHICLE MODEL.

<u>PART NO.</u>	<u>NOMENCLATURE</u>	<u>MODEL</u>	<u>QTY.</u>
12338186-69	SPACER, REAR	ALL	9
12338186-70	SPACER	M1114	1
12447142	SHIELD ASSEMBLY, FRONT	M1113 WO/W ONLY	1
12447143	SHIELD ASSEMBLY, INTERMEDIATE	ALL	1
12447144	SHIELD ASSEMBLY, REAR	ALL	1
12447145	BRACKET, REAR MOUNTING	ALL	3
12447146	BRACKET ASSY, L.H. SHIELD	ALL EXCEPT M1114	1
12447147	BRACKET ASSY, R.H. SHIELD	ALL EXCEPT M1114	1
12447148	BRACKET, TUBE SUPPORT	ALL	2
12447149	WASHER, SPECIAL	ALL	4
12447150	SHIELD, FUEL TANK	ALL	1
12447151	SHIELD, TRANSFER CASE	ALL	1
12447163-1	SKID PLATE	M1114 ONLY	1
12447163-2	SKID PLATE	M998A2 W/W ONLY	1
12447164	SKID PLATE	M1113 WO/W ONLY	1
12460145-1	SCREW	ALL	1
12460145-2	SCREW	ALL	1
12460291	INSTALLATION INSTRUCTIONS	ALL	1
12460292	INSTALLATION DRAWING	ALL	1
12460414	SKID PLATE	M998A2 WO/W ONLY	1
12460415	SHIELD ASSEMBLY, FRONT	ALL EXCEPT M1113 WO/W	1
12460499	ROD	M1114	1
12460500	BRACKET, L.H.	M1114	1
12460501	BRACKET, R.H.	M1114	1
MS51943-33	NUT	ALL	18
MS51943-35	NUT	ALL	20
MS51943-39	NUT	ALL	6
B1821BH038C100N	SCREW	ALL	5
B1821BH038C113N	SCREW	ALL	7
B1821BH038C150N	SCREW	ALL	2
172487	SCREW	M1114	1
453039	SCREW	ALL	6
2436162	WASHER	ALL	36
2436163	WASHER	ALL	40
2436165	WASHER	M1114	2
9422299	NUT	ALL	4

DRAWING CONTROL
CHANGE DATE
A/7-24-00

M998A2

TITLE INSTALLATION INSTRUCTIONS, UNDERBODY PROTECTION ACCESSORY KITS 57K3492, 57K3493, 57K3494, AND 57K3495	SIZE <div style="text-align: center; font-size: 1.5em;">A</div>	CAGE CODE <div style="text-align: center; font-size: 1.5em;">19207</div>	<div style="text-align: center; font-size: 2.5em; font-weight: bold;">12460291</div>		
		(AMG U1770)	00-07-24	REVISION LEVEL	SHEET 2

<u>PART NO.</u>	<u>NOMENCLATURE</u>	<u>MODEL</u>	<u>QTY.</u>
9428795	SCREW	ALL	5
9430677	SCREW	ALL	12
9430724	SCREW	ALL	1

2-2. THE FOLLOWING ITEM IS REQUIRED, BUT IS NOT INCLUDED IN THE KIT AND MUST BE REQUISITIONED.

<u>PART NO.</u>	<u>NOMENCLATURE</u>	<u>QTY.</u>
MIL-S-46163	SEALING COMPOUND	1

2-3. EXISTING MATERIAL. ALL MATERIAL REMOVED AND NOT REUSED DURING INSTALLATION WILL BE RETURNED TO STOCK FOR DISPOSITION IN ACCORDANCE WITH AR 725-50.

SECTION III. INSTALLATION PROCEDURE

3-1. VEHICLE PREPARATION.

- A. DISCONNECT BATTERY GROUND CABLES. (REFER TO TM 9-2320-280-20 OR TM 9-2320-387-24.)
- B. DRAIN FUEL FROM FUEL TANK. (REFER TO TM 9-2320-280-20 OR TM 9-2320-387-24.)
- C. REMOVE BRAKE ROTOR PROTECTION GUARDS FROM FRONT AND REAR CROSSMEMBERS. (REFER TO TM 9-2320-387-24.)
- D. REMOVE EIGHT GUARD BRACKETS FROM FRONT AND REAR CROSSMEMBERS BY REMOVING TWELVE SCREWS, TWENTY-FOUR WASHERS, AND TWELVE NUTS AS SHOWN IN FIGURE 1.

NOTE

REMOVE BURRS AND SHARP EDGES.

- E. CUT AND REMOVE SECTION OF REINFORCEMENT FROM CROSSMEMBER C AS SHOWN IN FIGURE 2.

3-2. FUEL TANK SHIELD INSTALLATION.

- A. REMOVE TWO NUTS, WASHERS, AND SCREWS FROM UPPER AND LOWER FUEL TANK STRAPS AS SHOWN IN FIGURE 3.

NOTE

REMOVE BURRS AND SHARP EDGES.

- B. REMOVE SECTION OF 12447150 FUEL TANK SHIELD AS SHOWN IN FIGURE 3.

NOTE

IF UPPER AND LOWER STRAPS TOUCH AFTER CORRECT TORQUE IS APPLIED TO SCREWS, STRAPS ARE UNSERVICEABLE AND MUST BE REPLACED.

- C. POSITION FUEL TANK SHIELD (12447150) TO BOTTOM OF FUEL TANK AND SECURE WITH TWO UPPER STRAPS, 12460145-1 SCREW, 12460145-2 SCREW, TWO EXISTING WASHERS, LOWER STRAPS, AND EXISTING NUTS AS SHOWN IN FIGURE 3. TIGHTEN SCREWS TO 23-27 LB-IN. (3 N-m).
- D. INSTALL EXISTING DRAIN PLUG IN FUEL TANK AS SHOWN IN FIGURE 3.

DRAWING CONTROL
CHANGE DATE
A / 7-24-00

M998A2

TITLE INSTALLATION INSTRUCTIONS, UNDERBODY PROTECTION ACCESSORY KITS 57K3492, 57K3493, 57K3494, AND 57K3495	SIZE A	CAGE CODE 19207	12460291		
	(AMG U1770)	00-07-24	REVISION LEVEL	A	SHEET 3

3-3. REAR CROSSMEMBER HOLE DRILLING.

- A. LOCATE, MARK, AND DRILL SIX 0.375-INCH DIAMETER HOLES IN REAR PANEL OF CROSSMEMBER A AS SHOWN IN FIGURE 4.

NOTE

ENSURE WHEN LOCATING HOLES THAT THEY ARE IN LINE WITH EXISTING DRILLED HOLES.

- B. USING HOLES DRILLED IN STEP A AS A GUIDE, LOCATE, MARK, AND DRILL SIX 0.375-INCH DIAMETER HOLES IN FRONT PANEL OF CROSSMEMBER A AS SHOWN IN FIGURE 4.
- C. LOCATE, MARK, AND DRILL THREE 0.438-INCH DIAMETER HOLES IN FRONT PANEL OF CROSSMEMBER B AS SHOWN IN FIGURE 5.

NOTE

ENSURE WHEN LOCATING HOLES THAT THEY ARE IN LINE WITH EXISTING DRILLED HOLES.

- D. USING HOLES DRILLED IN STEP C AS A GUIDE, LOCATE, MARK, AND DRILL THREE 0.438-INCH DIAMETER HOLES IN REAR PANEL OF CROSSMEMBER B AS SHOWN IN FIGURE 5.

3-4. FRONT CROSSMEMBER HOLE DRILLING.

NOTE

YOKE ON DIFFERENTIAL MAY HAVE TO BE TURNED TO ALLOW ACCESS TO MOUNTING BRACKET SCREW.

- A. REMOVE TWO SCREWS AND WASHERS SECURING FRONT DIFFERENTIAL TO MOUNTING BRACKET AS SHOWN IN FIGURE 6.
- B. REMOVE TWO SCREWS, FOUR WASHERS, TWO NUTS, AND MOVE MOUNTING BRACKET AWAY FROM REAR OF CROSSMEMBER C AS SHOWN IN FIGURE 7.
- C. REMOVE FOUR NUTS, WASHERS, AND LOWER SWAY BAR FROM LEFT AND RIGHT FRAME RAILS AS SHOWN IN FIGURE 8.

DRAWING CONTROL
CHANGE DATE
A/7-24-00

CAUTION

WHEN DRILLING, PLACE SCRAP METAL BETWEEN CROSSMEMBER C AND DISC BRAKE ROTOR TO ENSURE THAT DISC BRAKE ROTOR IS NOT DAMAGED.

NOTE

STEERING WHEEL MAY HAVE TO BE TURNED TO ALLOW ACCESS TO CROSSMEMBER DRILLING LOCATIONS.

- D. LOCATE, MARK, AND DRILL FOUR 0.438-INCH DIAMETER HOLES IN REAR PANEL OF CROSSMEMBER C AS SHOWN IN FIGURE 9.

M998A2

TITLE INSTALLATION INSTRUCTIONS, UNDERBODY PROTECTION ACCESSORY KITS 57K3492, 57K3493, 57K3494, AND 57K3495	SIZE A	CAGE CODE 19207	12460291		
	(AMG U1770)	00-07-24	REVISION LEVEL	A	SHEET 4

DRAWING CONTROL
CHANGE DATE
A/7-24-00

NOTE

- USE CARE WHEN DRILLING THROUGH HOLE IN REAR PANEL INTO FRONT PANEL OF CROSSMEMBER. IF ACCESSING PROPER HOLE LOCATION IS DIFFICULT, TRANSFER HOLE LOCATION TO FRONT SIDE OF FRONT PANEL FOR DRILLING OPERATION.
- ENSURE WHEN LOCATING HOLES THAT THEY ARE IN LINE WITH EXISTING DRILLED HOLES.

- USING HOLES DRILLED IN STEP D AS A GUIDE, LOCATE, MARK, AND DRILL THREE 0.438-INCH DIAMETER HOLES IN FRONT PANEL OF CROSSMEMBER C AS SHOWN IN FIGURE 9.
- APPLY MIL-S-46163 SEALING COMPOUND TO TWO EXISTING SCREWS AND SECURE MOUNTING BRACKET TO FRONT DIFFERENTIAL WITH TWO SCREWS AND WASHERS AS SHOWN IN FIGURE 6. TIGHTEN SCREWS TO 110 LB-FT (149 N-m).
- POSITION MOUNTING BRACKET ON REAR OF CROSSMEMBER C AND SECURE WITH TWO EXISTING SCREWS, FOUR WASHERS, AND TWO MS51943-39 NUTS AS SHOWN IN FIGURE 7. TIGHTEN SCREWS TO 90 LB-FT (122 N-m).
- POSITION LOWER SWAY BAR TO LEFT AND RIGHT FRAME RAILS AND SECURE WITH FOUR EXISTING WASHERS AND 9422299 NUTS AS SHOWN IN FIGURE 8.

3-5. REAR SHIELD INSTALLATION.

NOTE

WHEN INSTALLING SPACERS IN CROSSMEMBER, ENDS OF SPACERS MAY BE FILED FOR EASE OF INSTALLATION.

- POSITION THREE 12447145 MOUNTING BRACKETS TO CROSSMEMBER A AND SECURE WITH SIX 453039 SCREWS, TWELVE 2436162 WASHERS, SIX 12338186-69 REAR SPACERS, AND MS51943-33 NUTS AS SHOWN IN FIGURE 10. DO NOT TIGHTEN SCREWS.
- POSITION 12447144 REAR SHIELD ASSEMBLY TO TOP MOUNT HOLES ON THREE MOUNTING BRACKETS AND INSTALL THREE B1821BH038C113N SCREWS, SIX 2436163 WASHERS, AND THREE MS51943-35 NUTS AS SHOWN IN FIGURE 10. DO NOT TIGHTEN SCREWS.

NOTE

WHEN INSTALLING SPACERS IN CROSSMEMBER, ENDS OF SPACERS MAY BE FILED FOR EASE OF INSTALLATION.

- POSITION REAR SHIELD ASSEMBLY TO CROSSMEMBER B AND SECURE WITH THREE 9428795 SCREWS, SIX 2436163 WASHERS, THREE 12338186-69 REAR SPACERS, AND MS51943-35 NUTS AS SHOWN IN FIGURE 10. DO NOT TIGHTEN SCREWS.
- TIGHTEN SCREWS INSTALLED IN STEP A TO 24 LB-FT (32 N-m).
- TIGHTEN SCREWS INSTALLED IN STEPS B AND C TO 44 LB-FT (60 N-m).

3-6. TRANSFER CASE SHIELD INSTALLATION.

POSITION 12447151 TRANSFER CASE SHIELD ON TRANSMISSION CROSSMEMBER AND SECURE WITH TWO B1821BH038C100N SCREWS, FOUR 2436163 WASHERS, AND TWO MS51943-35 NUTS AS SHOWN IN FIGURE 11. TIGHTEN SCREWS TO 44 LB-FT (60 N-m).

M998A2

TITLE INSTALLATION INSTRUCTIONS, UNDERBODY PROTECTION ACCESSORY KITS 57K3492, 57K3493, 57K3494, AND 57K3495	SIZE A	CAGE CODE 19207	12460291		
	(AMG U1770)	00-07-24	REVISION LEVEL	A	SHEET 5

3-7. INTERMEDIATE SHIELD ASSEMBLY INSTALLATION.

NOTE

- STEPS A, B, AND F ARE FOR M998A2 SERIES AND M1113 VEHICLES.
- PROCEED TO STEPS C, D, E, AND G FOR M1114 VEHICLE INSTALLATION.
- STEPS H AND I ARE FOR ALL VEHICLES.

DRAWING CONTROL
CHANGE DATE
A/7-24-00
A1/7-25-00

- REMOVE SCREW, TWO WASHERS, AND NUT FROM LEFT FRAME RAIL. INSTALL 12447146 LEFT-HAND SHIELD BRACKET ON OUTSIDE OF LEFT FRAME RAIL WITH EXISTING SCREW, TWO WASHERS, AND MS51943-39 NUT AS SHOWN IN FIGURE 12. DO NOT TIGHTEN SCREW.
- REMOVE SCREW, TWO WASHERS, AND NUT FROM RIGHT FRAME RAIL. INSTALL 12447147 RIGHT-HAND SHIELD BRACKET ON INSIDE OF RIGHT FRAME RAIL WITH EXISTING SCREW, TWO WASHERS, AND MS51943-39 NUT AS SHOWN IN FIGURE 12. DO NOT TIGHTEN SCREW.
- REMOVE SCREW FROM TWO ~~FUEL LINE~~ ^{TRANSMISSION OIL COOLER TUBE} P-CLAMPS ON RIGHT FRAME RAIL AS SHOWN IN FIGURE 13.

NOTE

ENSURE WHEN POSITIONING BRACKET ON RIGHT FRAME RAIL THAT 0.75 DIA. BOSS ENGAGES INTO 0.75 DIA. HOLE IN RIGHT FRAME RAIL.

- POSITION 12460501 RIGHT-HAND BRACKET ON RIGHT FRAME RAIL BEHIND TWO ~~FUEL LINE~~ ^{TRANS. OIL COOLER} P-CLAMPS AND INSTALL WITH 172487 SCREW ^{INTO FRAME COOLER TUBE HOLE} AS SHOWN IN FIGURE 13. DO NOT TIGHTEN SCREW.
- POSITION 12460499 ROD IN LEFT ENGINE MOUNT AND INSTALL 12338186-70 SPACER, 12460500 LEFT-HAND BRACKET, TWO 2436165 WASHERS, AND MS51943-39 NUTS AS SHOWN IN FIGURE 14. DO NOT TIGHTEN NUTS.

NOTE

ENSURE TWO TUBE SUPPORTS ARE POSITIONED ON TOP OF TRANSMISSION CROSSMEMBER WHEN INSTALLING INTERMEDIATE SHIELD TO MOUNTING BRACKET.

- POSITION 12447143 INTERMEDIATE SHIELD ASSEMBLY TO LEFT- AND RIGHT-HAND SHIELD BRACKETS. INSTALL EIGHT 9430677 SCREWS, SIXTEEN 2436162 WASHERS, AND EIGHT MS51943-33 NUTS AS SHOWN IN FIGURE 12. DO NOT TIGHTEN NUTS.
- POSITION 12447143 INTERMEDIATE SHIELD ASSEMBLY TO LEFT- AND RIGHT-HAND BRACKETS. INSTALL FOUR 9430677 SCREWS, EIGHT 2436162 WASHERS, AND FOUR MS51943-33 NUTS AS SHOWN IN FIGURE 15. DO NOT TIGHTEN NUTS.
- POSITION TWO 12447148 TUBE SUPPORT SHIELD BRACKETS, B1821BH038C150N SCREWS, FOUR 2436163 WASHERS, 12447149 SPECIAL WASHERS, AND TWO MS51943-35 NUTS THROUGH 12447143 INTERMEDIATE SHIELD ASSEMBLY AND TRANSMISSION CROSSMEMBER AS SHOWN IN FIGURE 12. DO NOT TIGHTEN SCREWS.
- SECURE TWO TUBE SUPPORT BRACKETS TO TRANSMISSION CROSSMEMBER WITH FOUR 9430677 SCREWS, EIGHT 2436162 WASHERS, AND FOUR MS51943-33 NUTS AS SHOWN IN FIGURE 12. DO NOT TIGHTEN SCREWS.

M998A2

TITLE INSTALLATION INSTRUCTIONS, UNDERBODY PROTECTION ACCESSORY KITS 57K3492, 57K3493, 57K3494, AND 57K3495	SIZE A	CAGE CODE 19207	12460291		
	(AMC U1770)	00-07-24	REVISION LEVEL	A	SHEET 6

3-8. FRONT SKID PLATE INSTALLATION.

DRAWING CONTROL
CHANGE DATE
1/7-24-00

NOTE

- FOR M998A2 SERIES VEHICLES WITH WINCH, PERFORM STEP A.
 - FOR M1113 VEHICLE WITHOUT FRONT HYDRAULIC WINCH, PERFORM STEP B.
 - FOR M998A2 SERIES VEHICLE WITHOUT FRONT WINCH, PERFORM STEP C.
 - FOR M1114 VEHICLE WITH REAR WINCH, PERFORM STEP D.
 - FOR M1113 VEHICLE WITH FRONT HYDRAULIC WINCH, PERFORM STEP G.
- A. POSITION 12447163-2 SKID PLATE ON FRONT BUMPER AND SECURE WITH TWO B1821BH038C100N SCREWS, FOUR 2436163 WASHERS, AND TWO MS51943-35 NUTS AS SHOWN IN FIGURE 16. DO NOT TIGHTEN SCREWS.
 - B. POSITION 12447164 SKID PLATE ON FRONT BUMPER AND SECURE WITH THREE B1821BH038C100N SCREWS, SIX 2436163 WASHERS, AND THREE MS51943-35 NUTS AS SHOWN IN FIGURE 17. DO NOT TIGHTEN SCREWS.
 - C. POSITION 12460414 SKID PLATE ON FRONT BUMPER AND SECURE WITH THREE B1821BH038C100N SCREWS, SIX 2436163 WASHERS, AND THREE MS51943-35 NUTS AS SHOWN IN FIGURE 18. DO NOT TIGHTEN SCREWS.
 - D. POSITION 12447163-1 SKID PLATE ON FRONT BUMPER AND SECURE WITH THREE B1821BH038C100N SCREWS, FIVE 2436163 WASHERS, AND TWO MS51943-35 NUTS AS SHOWN IN FIGURE 19. DO NOT TIGHTEN SCREWS.

NOTE

- FOR M998A2 W/WINCH AND W/O WINCH SERIES AND M1114 VEHICLES, PERFORM STEP E.
 - FOR M1113 VEHICLES WITHOUT HYDRAULIC WINCH, PERFORM STEP F.
- E. POSITION 12460415 FRONT SHIELD TO SKID PLATE AND INSTALL THREE B1821BH038C113N SCREWS, SIX 2436163 WASHERS, AND THREE MS51943-35 NUTS AS SHOWN IN FIGURES 16, 18, AND 19. DO NOT TIGHTEN SCREWS.
 - F. POSITION 12447142 FRONT SHIELD TO SKID PLATE AND INSTALL THREE B1821BH038C113N SCREWS, SIX 2436163 WASHERS, AND THREE MS51943-35 NUTS AS SHOWN IN FIGURE 17. DO NOT TIGHTEN SCREWS.
 - G. POSITION 12460415 FRONT SHIELD TO BUMPER PLATE AND INSTALL THREE B1821BH038C113N SCREWS, SIX 2436163 WASHERS, AND THREE MS51943-35 NUTS AS SHOWN IN FIGURE 21. DO NOT TIGHTEN SCREWS.
 - H. INSTALL FRONT SHIELD AND INTERMEDIATE SHIELD ASSEMBLY TO CROSSMEMBER C WITH 9430724 SCREW, TWO 2436163 WASHERS, AND MS51943-35 NUT AS SHOWN IN FIGURE 20. DO NOT TIGHTEN SCREW.
 - I. INSTALL FRONT SHIELD ON CROSSMEMBER C WITH B1821BH038C113N SCREW, TWO 2436163 WASHERS, AND MS51943-35 NUT AS SHOWN IN FIGURE 20. DO NOT TIGHTEN SCREW.

TITLE INSTALLATION INSTRUCTIONS, UNDERBODY PROTECTION ACCESSORY KITS 57K3492, 57K3493, 57K3494, AND 57K3495	SIZE A	CAGE CODE 19207	M998A2 12460291	
	(AMG U1770)	00-07-24		

- J. INSTALL INTERMEDIATE SHIELD ASSEMBLY ON CROSSMEMBER C WITH 9428795 SCREW, TWO 2436163 WASHERS, AND MS51943-35 NUT AS SHOWN IN FIGURE 20. DO NOT TIGHTEN SCREW.
- K. INSTALL FRONT SHIELD TO CROSSMEMBER C WITH 9428795 SCREW, TWO 2436163 WASHERS, AND MS51943-35 NUT AS SHOWN IN FIGURE 20. DO NOT TIGHTEN SCREW.

NOTE

DURING INSTALLATION, MOUNTING SCREWS OR NUTS WERE NOT TIGHTENED TO ALLOW FOR ALIGNMENT OF SKID PLATE, FRONT SHIELD, AND INTERMEDIATE SHIELD.

- L. TIGHTEN SCREWS OR NUTS INSTALLED IN PARA. 3-7, STEPS A, B, E, AND G TO 90 LB-FT (122 N-m).
- M. TIGHTEN SCREWS OR NUTS INSTALLED IN PARA. 3-7, STEPS F, H, AND J TO 24 LB-FT (33 N-m).
- N. TIGHTEN SCREWS INSTALLED IN PARA. 3-7, STEPS D AND I AND PARA. 3-8, STEPS A THROUGH J TO 44 LB-FT (60 N-m).

3-9. FINAL PREPARATION.

NOTE

ENSURE FUEL HAS NOT BEEN CONTAMINATED.

- A. RETURN FUEL TO TANK AND CHECK FOR LEAKS.
- B. CONNECT BATTERY CABLES. (REFER TO TM 9-2320-280-20 OR TM 9-2320-387-24.)

DRAWING CONTROL
CHANGE DATE A/7-24-00

M998A2

TITLE INSTALLATION INSTRUCTIONS, UNDERBODY PROTECTION ACCESSORY KITS 57K3492, 57K3493, 57K3494, AND 57K3495	SIZE A	CAGE CODE 19207	12460291		
	(AMG U1770)	00-07-24	REVISION LEVEL	A	SHEET 8

ZONE	REV	DESCRIPTION	DATE	APPROVED
		PRODUCT BASELINE		
		ERR AMG P9546	98-01-23	JRC
D7	A	(1) REVISE VIEW (2) REVISE REV STATUS BLK		
B1		(3) SEE SH 3 (4) SEE SH 4		
		(AMG U1770)	00-07-24	CD

DRAWING CONTROL	CHANGE NO.	CHG. LET.	CHANGE	DATE	DR	CR
CHANGE DATE	144-5100		PROD. RELEASE	10-13-98	KJ	
144-5100			REV. A 48118 PPK	1-28-02		SE
144-5100			REV. A 48118 PPK	1-28-02		SE
144-5100			REV. A 48118 PPK	1-28-02		SE




FIGURE 1

- NOTES:
1. APPLICABLE STANDARDS/SPECIFICATIONS:
 - A. DOD-STD-401000/401
 2. THIS DRAWING IS FOR INSTALLATION PURPOSES ONLY. ALL ITEMS MARKED * ARE INCLUDED IN KIT.
 3. CALLOUTS IDENTIFIED AS FOLLOWS:
 - * NEW PARTS
 - * PARTS TO BE REMOVED AND DISCARDED
 - * PARTS TO BE REMOVED AND REUSED

A	A	A
SHEET 4	SHEET 3	SHEET 2
SHEET 1		
REVISION STATUS OF SHEETS		

M998A2

PART NO.

PAC NA		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES 3 PLACE		CONTRACT NUMBER DAAG07-80-C-9010		DESIGN ACTIVITY U.S. ARMY TANK-AUTOMOTIVE COMMAND WARREN, MICHIGAN 48397-5000	
57K3495		M1116		AM General Corp.		INSTALLATION DRAWING	
57K3494		M1116		AM General Corp.		UNDERBODY PROTECTION ACCESSORY	
57K3493		SERIES		AM General Corp.		KITS 57K3492, 57K3493, 57K3494,	
57K3492		M998A2		AM General Corp.		AND 57K3495	
NEXT ARMY		USED ON		DATE		SIZE	
APPLICATION		DATE		DATE		E 19207 12460292	
						SCALE NONE UNIT WT SHEET 1 OF 4	




FIGURE 2




FIGURE 3

FIGURE 4









FIGURE 5






FIGURE 10





FIGURE 11







2743

PART NO.		DESIGN ACTIVITY	
U.S. ARMY TANK AUTOMOTIVE COMMAND WARREN, MICHIGAN 48397-5000		UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES	
INSTALLATION DRAWING		TOL. FINISH ON 1 PLATE 3 IN. ACN	
UNDERBODY PROTECTION ACCESSORY KITS 5TK3492, 5TK3493, 5TK3494, AND 5TK3495		Q1. HUBERT <i>Hubert</i> DESIGN MANAGER W/LEADER <i>W. L. Hubert</i>	
SIZE		CONTRACT NUMBER	
E 19207		DAAB07-22-C-0010	
CAGE CODE		CONTRACTOR	
12460292		AM General Corp.	
SCALE NONE		Drawing Date 3-7-68, Issue 1, Approved 8-4-68	
UNIT WT		DRAWN BY	
SHEET 3		DATE 1-15-68	
		CHECKED BY	
		DATE 1-15-68	
		ENGINEER	
		DATE 1-15-68	
		DRAWING APPROVAL	
		DATE 3-10-68	
		DESIGN APPROVAL	
		DATE 3-10-68	
		APPROVAL	
		DATE 3-10-68	


ZONE		REV	DESCRIPTION	DATE	APPROVED
A4		A	(3) REVISE NOTE		
			PRODUCT BASELINE ERR AMG P9546	98-01-23	SR
			(AMG U1770)	00-07-24	ED

DRAWING CONTROL		AM General Corporation				
CHANGE DATE	CHANGE NO.	CHG. LET.	CHANGE	DATE	DR.	CK.
R2/-23-98	14-493		PROD. RELEASE	10-17-98	RS	
A/7-24-00	14-S1008		REV. A ADD 370 AS4 REV. 00-101M REV U 1720	1-23-02	SE	
A/7-25-00	14-S1204	A11	R/S FOR 2 LUG. END 11012, 1000-T 2629	2-13-03	SE	






M9942 SERIES WITH WINCH
FIGURE 16



M1113 VEHICLE WITHOUT WINCH
FIGURE 17

REVISION		DESCRIPTION	DATE	APPROVED
ZONE	REV			
U18		PRODUCT BASELINE ERR AMG P9546	98-01-23	SPR
C2 A		ADDED FIG 21 (AMG U1770)	00-07-24	(S)

AM General Corporation				
DRAWING CONTROL	CHANGE NO.	CHG. LET.	CHANGE	DATE
CHANGE DATE	144-498		PROD. RELEASE	14-09-98
14-09-98				1-23-02
14-09-98				1-23-02





FOR M998A2 SERIES WITHOUT WINCH
FIGURE 18

M998A2

PART NO.

UNLESS OTHERWISE SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES ON 1 PLACE 3 PLACE		CONTRACT NUMBER DAAE07-92-C-8010 AM General Corp.	
QA AUDIT DESIGN MANAGER ELM	DATE 14-09-98	DESIGN APPROVAL 14-09-98	DATE 14-09-98
DRAWING APPROVAL 14-09-98		DATE 14-09-98	
NEXT ASSY USED ON		SCALE NONE UNIT WT	
APPLICATION		SHEET 4	






FIGURE 21